
Thin-Walled Pressure Vessels





PLANE



— Azisymmetry

No variation in θ -div $\frac{\partial}{\partial \theta}()=0$

No loading in 9-dis => v = 0

$$\frac{\partial}{\partial \theta}() = 0 + \vartheta = 0$$

$$\sum_{\text{For cipal}} = 0 \Rightarrow Z_{\text{FO}} = 2G & E_{\text{FO}} = 0$$

$$\sum_{\text{For cipal}} \text{Stresses} \qquad Cylardrical$$

$$T_{20} = 0$$


$$T_{82} = 0$$

$$2\times (\overline{0}, t \Delta x) = P 2 \times \Delta x$$

$$\Rightarrow \overline{0}_1 = \frac{P \delta}{t} Circ$$


$$\Rightarrow \overline{0}_1 = \frac{P \delta}{t} H_{\delta 2}$$

Circumferential




$$\begin{array}{cccc}
\hline
\sigma_2 & 2\pi & \tau & = & p\pi \\
\hline
\uparrow & & & \\
\hline
\uparrow & & & \\
\hline
\sigma_2 & = & \frac{P & \tau}{2 & \tau} & \rightarrow & \text{Longitudinal} \\
\hline
\uparrow & & & \\
\hline
\uparrow & & & \\
\hline
\uparrow & & & \\
\hline
\end{array}$$
Longitudinal


$$\sigma_1 = 2\sigma_2$$





$$\frac{\sigma 2\pi rt = \rho \pi r}{2}$$




1. The thin-walled cylinder can be supported in one of two 6 mm. [(a) 12.5 MPa, 0 MPa (b) 12.5 MPa, 6.25 MPa]







5. The thin-walled cylindrical pressure vessel shown in the figure is subjected to an internal gauge pressure of 15 MPa. If the thickness is 10 mm, and the material constants are E=200 GPa and $\nu=0.3$, determine the increase in both the diameter and the length of the pressure vessel. [3.19 mm, 2.25 mm]



$$\begin{aligned}
\nabla_{1} &= \frac{\rho Y}{\tau} , & \nabla_{2} &= \frac{\rho Y}{2\tau} , & \nabla_{6} Y \approx 0 \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{2} Z) \right] \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{2} Z) \right] \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{2} Z) \right] \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{2} Z) \right] \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{2} Z) \right] \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{2} Z) \right] \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{2} Z) \right] \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{2} Z) \right] \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{2} Z) \right] \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{2} Z) \right] \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{2} Z) \right] \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{2} Z) \right] \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{2} Z) \right] \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{2} Z) \right] \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{2} Z) \right] \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{2} Z) \right] \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{2} Z) \right] \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{2} Z) \right] \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{2} Z) \right] \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{2} Z) \right] \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{2} Z) \right] \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{6} Y \right] \\
& = \frac{1}{E} \left[\nabla_{6} \varphi - \nabla (\nabla_{6} Y + \nabla_{6} Y +$$

$$\frac{1}{2z} = \frac{(L+\Delta L)-L}{L} = \frac{\Delta L}{L} \Rightarrow \Delta L = \frac{\varepsilon_{22}L}{2}$$

$$\frac{2}{2} = \frac{0.5}{0.01} = \frac{1}{2}$$

4. A thin walled spherical pressure having an inner radius r and thickness t is subjected to an internal pressure p. Show that the increase in the volume within the vessel is $\Delta V = \frac{2p\pi r^4}{F^4}(1-\nu)$. Use a small-strain analysis.




$$\begin{aligned}
\nabla &= \frac{\partial Y}{2\tau} \times \\
V &= \frac{L_1}{3}\pi 6^3 \\
V + DV &= \frac{L_1}{3}\pi (Y + DY) = \frac{4}{3}\pi 6^3 \left(1 + \frac{DY}{Y}\right) \\
&= \frac{\Delta Y}{3} \times 1 \\
\therefore Y + DV &\approx \frac{4}{3}\pi 6^3 \left(1 + 3\frac{DY}{Y}\right) \\
\vdots &\Rightarrow DV &= \frac{4}{3}\pi 8^3 \left(3\frac{DY}{Y}\right)
\end{aligned}$$

$$\begin{aligned}
& = \frac{1}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{1}{2} \left(\frac{\sigma_0}{\sigma_0} + \frac{\sigma_0}{\sigma_0} \right) \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{1}{2} \left(\frac{\sigma_0}{\sigma_0} + \frac{\sigma_0}{\sigma_0} \right) \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{1}{2} \left(\frac{\sigma_0}{\sigma_0} + \frac{\sigma_0}{\sigma_0} \right) \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{1}{2} \left(\frac{\sigma_0}{\sigma_0} + \frac{\sigma_0}{\sigma_0} \right) \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{1}{2} \left(\frac{\sigma_0}{\sigma_0} + \frac{\sigma_0}{\sigma_0} \right) \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{1}{2} \left(\frac{\sigma_0}{\sigma_0} + \frac{\sigma_0}{\sigma_0} \right) \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{1}{2} \left(\frac{\sigma_0}{\sigma_0} + \frac{\sigma_0}{\sigma_0} \right) \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{1}{2} \left(\frac{\sigma_0}{\sigma_0} + \frac{\sigma_0}{\sigma_0} \right) \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{1}{2} \left(\frac{\sigma_0}{\sigma_0} + \frac{\sigma_0}{\sigma_0} \right) \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{1}{2} \left(\frac{\sigma_0}{\sigma_0} + \frac{\sigma_0}{\sigma_0} \right) \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{1}{2} \left(\frac{\sigma_0}{\sigma_0} + \frac{\sigma_0}{\sigma_0} \right) \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{1}{2} \left(\frac{\sigma_0}{\sigma_0} + \frac{\sigma_0}{\sigma_0} \right) \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{1}{2} \left(\frac{\sigma_0}{\sigma_0} + \frac{\sigma_0}{\sigma_0} \right) \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{\sigma_0}{\sigma_0} \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{\sigma_0}{\sigma_0} \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{\sigma_0}{\sigma_0} \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{\sigma_0}{\sigma_0} \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{\sigma_0}{\sigma_0} \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{\sigma_0}{\sigma_0} \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{\sigma_0}{\sigma_0} \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{\sigma_0}{\sigma_0} \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{\sigma_0}{\sigma_0} \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{\sigma_0}{\sigma_0} \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{\sigma_0}{\sigma_0} \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{\sigma_0}{\sigma_0} \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{\sigma_0}{\sigma_0} \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{\sigma_0}{\sigma_0} \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{\sigma_0}{\sigma_0} \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{\sigma_0}{\sigma_0} \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{\sigma_0}{\sigma_0} \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{\sigma_0}{\sigma_0} \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{\sigma_0}{\sigma_0} \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{\sigma_0}{\sigma_0} \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{\sigma_0}{\sigma_0} \right] \\
& = \frac{\sigma_0}{E} \left[\frac{\sigma_0}{\sigma_0} - \frac{\sigma_0}{\sigma_0} \right] \\$$

- 6. Air is pumped into the steel thin-walled presure vessel at C. The inner radius of the pressure vessel is 400 mm, and its thickness is 10 mm. For steel: E=200 GPa and $\nu=0.3$.
 - (a) If the ends of the vessel are closed using two pistons connected by a rod AB, determine the increase in the diameter of the pressure vessel when the internal gauge pressure is 5 MPa. Also, what is the tensile stress in rod AB if it has a diameter of 100 mm?
 - (b) If the pistons in part (a) are replaced by walls connected to the ends of the vessel, determine the increase in the diameter of the pressure vessel.

[(a) 0.800 mm, 315 MPa, (b) 0.680 mm]



$$G_{1} = \frac{pr}{t}, G_{2} = 0$$

$$F = P(\pi r^{2} - \pi r^{2} od)$$

$$G_{7} = \frac{F}{\pi r^{2} od}$$

15. The drill is jammed in the wall and is subjected to the torque and force shown. Determine the state of stress at points A and B on the cross section of drill bit at section a-a.

$$[\sigma_A = 215 \text{ MPa (C)},$$

$$(\tau_{xy})_A = 0, (\tau_{xz})_A = 102 \text{ MPa},$$

$$\sigma_B = 1.53 \text{ MPa (C)},$$


$$(\tau_{xy})_B = \tau_{\text{torsion}} - \tau_{\text{transverse}} = 100.33 \text{ MPa]}$$


$$\sum F_{\chi} = 0 \Rightarrow N_{\chi} + 150 \left(\frac{4}{5}\right) N = 0$$

$$\Rightarrow N_{\chi} = -120 N$$

$$\sum F_{\chi} = 0 \Rightarrow V_{\chi} + 150 \left(\frac{3}{5}\right) N = 0$$


$$\Rightarrow V_{\chi} = -90 N$$





$$\sum M_z = 0$$

 $\frac{1}{2} T_z + 20N_m = 0$
 $\frac{1}{2} T_z = -20N_m$





$$\sum_{1}^{3} M_{z}^{2} = 0 \Rightarrow M_{z} + 150 (E) N(0.125 m) - 150 N(E) N(0.400 m) = 0$$

$$\Rightarrow M_{z} = 21 N_{m}$$

$$\sigma_{A} = -\frac{|N_{x}|}{A} - \frac{|M|}{A}$$

$$\left. \begin{array}{c} T_{xy} \\ A \end{array} \right|_{A} = \left(\begin{array}{c} V_{y} Q_{z} \\ \overline{I_{z}} t \end{array} \right) = 0$$





$$\sigma_{\rm B} = -\frac{|N_{\rm x}|}{A} \qquad (c)$$


$$T_{xy} = |T_x|y$$


$$= T_z \tau$$
 $T_z \tau$


$$Q_{z} = \left(\frac{4x}{3\pi}\right)\left(\frac{1}{2}\pi x^{2}\right)$$

$$T_{z} = \frac{\pi}{4}x^{4}$$

$$t = 2x^{4}$$









16. The 25 mm diameter rod is subjected to the loads shown. Determine the state of stress at points A and B.

$$[\sigma_A = 49.61 \text{ MPa (C)}, \tau_A = 10.39 \text{ MPa}, \\ \sigma_B = 40.84 \text{ MPa (C)}, \tau_B = 9.58 \text{ MPa}]$$



$$\sum_{z=0}^{z} f_{z} = 0 \Rightarrow V_{z} + 450N = 0 \Rightarrow V_{z} = -450N$$

$$\sum_{z=0}^{z} f_{z} = 0 \Rightarrow N_{z} - 350N = 0 \Rightarrow N_{z} = 350N$$



$$| \sum F_{y} = 0 \Rightarrow \sqrt{y} - 375N = 0 \Rightarrow \sqrt{y} = 375N$$

$$| \sum M'_{z} = 0 \Rightarrow M_{z} + 375N \times 0.200m \Rightarrow M_{z} = -75N m$$

$$| \sum M'_{z} = 0 \Rightarrow M_{z} + 450N \times 0.200m - 350N \times 0.075m = 0$$


$$| \sum M'_{y} = 0 \Rightarrow M_{y} + 450N \times 0.200m - 350N \times 0.075m = 0$$


$$| \sum M'_{y} = 0 \Rightarrow M_{y} + 375N \times 0.075m \Rightarrow T_{z} = -28.125$$


$$| \sum M'_{x} = 0 \Rightarrow T_{x} + 375N \times 0.075m \Rightarrow T_{z} = -28.125$$

$$D_{A} = \frac{|N_{x}|}{A} + \frac{|M_{z}|_{x}}{I_{z}}$$

$$\left| \frac{Z_{xy}}{B} \right| = \frac{T_{obs}ien + T_{ransverse loading}}{\frac{|V_{y}|Q}{J} + \frac{|V_{y}|Q}{|T_{z}|^{2}}}$$









$$\begin{aligned}
I_z &= \frac{\pi}{4} x^4 \\
I_y &= I_z \\
J &= \frac{\pi}{2} x^4 \\
Q &= \frac{4x}{3x} \times \frac{1}{2} x^3 \\
A &= x^2 \\
T_{\pi Z} &= 0 \\
B &= 0
\end{aligned}$$

19. A close-coiled spring is made of a circular wire of radius r tht is formed into a helix of radius R. Determine the maximum shearing stress produced by the two equal and opposite forces P and P'. (First determine the shear and the torque in a transverse cross section of the $\left[\tau_{\text{max}} = \frac{P}{\pi r^3} \left(2R + \frac{4r}{3}\right)\right]$ wire.)







$$T = PR$$


$$T_{V} = \frac{VQ}{Tt}$$

$$T_{T} = \frac{T_{Y}}{T}$$

10. A brass ring of 126 mm outer diameter and 6 mm thickness fits exacts inside a steel ring of 126 mm inner diameter and 3 mm thickness when the temperature of boths rings is 10° . Knowing that the temperature of both rings is then raised to 52° , determine the pressure exerted by the brass ring on the steel ring and the tensile stress in the steel ring. Note that the strain due to temperature change is given by $\varepsilon_T = \alpha \Delta T$ and the strains due to pressure and temperature change add up to give the total strain. [1.67 MPa, 35.1 MPa]








$$\mathcal{C}_{Bh} = \frac{-Pr}{t}, \quad \mathcal{C}_{B,k} = 0$$

$$\mathcal{E}_{B} = \frac{1}{E_{B}} \left[\mathcal{C}_{B,h} - \mathcal{V} \left(\mathcal{C}_{B,k} + \mathcal{C}_{B,k} \right) \right] = 0$$

$$= 0 = 0$$

$$+ \mathcal{E}_{T}$$
Brass



2. A boiler is constructed of 8 mm thick steel plates that are fastened together at their ends using a butt joint consisting of two 8 mm thick cover plates and rivets having a diameter of 10 mm and spaced 50 mm apart as shown. If the steam pressure in the boiler is 1.35 MPa, determine (a) the hoop stress in the boiler plate apart from the seam, (b) the hoop stress in the outer cover plate along the rivet line a-a, and (c) the shear stress in the rivets. [(a) 127 MPa, (b) 79.1 MPa, (c) 322 MPa]

